UTAH TRANSIT AUTHORITY RIDESHARE/VAN-POOL(2017 AND NEWER ONLY) FORD TRANSIT PREVENTATIVE MAINTENANCE INSPECTION CHECKLIST		
VEHICLE UNIT NUMBER:	MileA	GE:
DATE OF SERVICE:	LAST 6 OF VIN NUME	ER:
VENDOR NAME:	LICENSE PLATE NUMB	ER:
MECHANIC NAME:		ER:
	UTA APPROVAL (NA	ме):

INDICATE IN SLOT to indicate whether an item was okay, adjust, and/or repairs are needed... Using As Labeled:

"V "= Okay - Item checked is ready for service.

- "X" = Adjust Item checked has been replaced and is ready for service:
- "**0**" = Repairs needed Any items requiring repair.

UPDATE MAINTENANCE REMINDER STICKER TO 7,500 MILES OR EVERY EIGHT-MONTHS

<u>"E" Service Inspection</u> (No Oil Change) (7,500 Miles or Eight-Months whichever comes first)

- ____01. Change Engine Oil, Replace Oil Filter & Reset Oil-Life Monitor (Use Only OEM Recommended Oil & Filter
- 02. Lubricate All Chassis & Steering Linkages as Required
- 03. Rotate & Inspect Tires for Wear
- ____04. Check All Lug Nuts (Torque to OEM specification)
- 05. Check & Record Tire Pressure (Including Spare)
- 06. Brake Fluid: (If Low Contact UTA)
- ____07. Check & "Top Off" All Fluids Using OEM Recommended Fluids
- 08. Coolant Level
- ___09. Transmission Fluid Level (If equipped w/dipstick)
- ____10. Power Steering Fluid Level
- 11. Windshield Washer Fluid Level
- 12. Safety Equipment Checks: Horn & Seat Belts
- ____13. Check Instruments & Dash Lights for Operation
- ____14. Check Heating & A/C Operations, Switches & Temperature Controls
- ___15. Check Exterior Lights, Turn Signal & 4 Way Hazard Warning Lights
- ____16. Check Wiper Operation & Blade Condition
- 17. Check Washer Operation & Spray Patterns
- ___18. Check Battery terminals & Charging Voltage, Voltage Reading: _____
- ___19. Inspect Engine Air Filter Element (replace as necessary)
- 20. Inspect Serpentine / Accessory Belts
- 21. Inspect Engine/Transmission & Differential leaks
- 22. Parking Brake Operation
- 23. Inspect and record brake pads/linings wear
- 24. Caliper Condition
- ___25. Rotor Condition
- 26. Check Brake Hoses & Lines for Damage & Leaks
- 27. Inspect Driveline & U-Joints for Wear
- 28. Check Exhaust System for Leaks or Broken Hangers
- 29. Inspect Suspension, Steering, Shocks, CV axles and boots
- ___30. Inspect Fuel System for Leaks
- ____31. Inspect All Coolant Hoses for Leaks and Wear

30,000 Mile "D" Service Inspection (Also includes "E" service)

- 32. Replace Cabin Air Filter
- 33. Inspect & Tighten Driveshaft Bolts
- ___34. Check Differential Fluid Level (Motorcraft Premium SAE 75W-85 Synthetic Hypoid Gear Oil)

60,000 Mile "C" Service Inspection (Also includes "D" and "E" services)

___35. Replace Serpentine/Accessory Belt as Required

90,000 Mile "B" Service Inspection (Also includes "D" and "E" services)


__36. Change & Flush Cooling System "Use OEM or Equivalent"

120,000 Mile "A" Service Inspection

(Also includes "C", "D" and "E" services)

- ____37. Change Automatic Transmission Fluid & Filter
- ____38. Change Rear Axle Fluid
- ____39. Replace Sparkplugs

Please record Tire Pressure, Tread depth and brake measurements at every maintenance service.



If "NO" please notify UTA Vanpool Maintenance